



## OPERATION MANUAL & SAFETY INSTRUCTIONS

# VARI-DISC *DUO*



**OPICO LIMITED**  
Cherry Holt Road  
Bourne  
Lincolnshire PE10 9LA  
Telephone: 01778 421111  
Fax: 01778 425080  
Email: [ask@opico.co.uk](mailto:ask@opico.co.uk)  
Website: [www.opico.co.uk](http://www.opico.co.uk)

Version: 12 04 Vari Disc duo PV



# INDEX

<b>GLOSSARY .....</b>	<b>3</b>
<b>INTRODUCTION .....</b>	<b>4</b>
<b>1. PURPOSE OF THE VARIO-DISC SKYROS .....</b>	<b>5</b>
<b>2. LIABILITY AND WARRANTY .....</b>	<b>5</b>
<b>3. DANGER AND SAFETY DECALS.....</b>	<b>6</b>
<b>4. POSITION OF DECALS.....</b>	<b>8</b>
<b>5. SAFETY INSTRUCTIONS .....</b>	<b>9</b>
5.1 GENERAL.....	9
5.2 ROAD TRANSPORT AND USE .....	9
5.3 MOUNTING AND DISMOUNTING .....	10
5.4 HYDRAULIC SYSTEM.....	10
5.5 MAINTENANCE.....	11
5.6 TYRES.....	12
<b>6. MOUNTING AND DISMOUNTING .....</b>	<b>13</b>
6.1 MOUNTING .....	13
6.2 TRANSPORT WITH A LENGTH TRANSPORT PROVISION .....	14
6.3 DISMOUNTING AND STORING .....	14
<b>7. ADJUSTING THE VARIO DISC. ....</b>	<b>15</b>
7.1 ADJUSTING THE WORKING DEPTH .....	15
7.2 ADJUSTING THE WORKING DEPTH WITHOUT THE ROLLER .....	16
7.3 ADJUSTING THE DISCS .....	16
<b>8. INSTRUCTIONS FOR USE .....</b>	<b>17</b>
<b>9. MAINTENANCE.....</b>	<b>18</b>
9.1 GENERAL.....	18
9.2 LUBRICATION .....	19
9.3 STANDARD DISC BEARING .....	19
<b>10. TECHNICAL SPECIFICATIONS.....</b>	<b>20</b>
<b>11. ORDERING PARTS .....</b>	<b>21</b>
<b>12. EC CERTIFICATE OF CONFORMITY.....</b>	<b>22</b>
<b>APPENDIX I: MOUNTING INSTRUCTIONS AND PARTSLIST.....</b>	<b>23</b>
I.1 RECOMMENDED MACHINE PLACEMENT FOR MOUNTING THE HUBS AND DISCS:.....	23
I.2 VARIO DISC Ø 51/56 CM.....	24
I.3 ASSEMBLY HUB VARIO-DISC .....	25
I.4 TUBE ROLLER .....	26
I.5 LOWER HITCH PIN / TOP LINK PIN / DEPTH CONTROL PIN .....	27
I.6 IDENTIFICATION PLATE, PATENT PLATE AND SAFETY DECALS.....	28

## GLOSSARY



If you come across this symbol and heading, there is a direct hazard to life and health of man and animal!



This heading refers to possible risks of damage to machine(s), crops, buildings, etc. But also to possible financial and/or legal problems (warranty, liability, and the like)!

## NOTE

This indicates a tip to make work easier, better and safer.

All figures, dimensions and weights are free of engagement.

References to direction in the text, such as "left", "right", "front" and "rear", are always meant to be seen from the forward travel direction of the tractor.

The same applies to the directions clockwise and counter clockwise.

# INTRODUCTION

Dear user,

This is the operation manual for the Vari-Disc Duo, types 300 and 330.



Read the operation manual carefully before starting to work with the machine and observe all instructions!

Pass on all safety instructions to other (fellow) users!

In order to use the Vario-Disc as safely as possible, you should be well aware of all recommendations and instructions in this manual. Damage and accidents caused by non-observance of these recommendations and instructions are for your responsibility.

Make sure to store this operation manual carefully and in a safe place for future use.

Please apply to your dealer in case there should still be questions after reading this manual.

EVERS AGRO B.V.  
Almelo, 16 May 2012

# 1. PURPOSE OF THE VARIO-DISC SKYROS

## Field of application

The Vario-Disc Skyros is solely for use in regular arable farming. It is suitable for cutting up crop remains on all fields where (much) haulm is left after harvesting. Examples are grain or silage maize, CCM, gladiolus, peas, potatoes, cereals, etc.

The machine can also be used for chapped straw and for incorporating lime and/or fertilizer. For a number of soil disinfection methods, chemicals can also be incorporated. The same applies to grass green manure and white mustard. On the lighter sandy soils it is possible to retreat the sward in 2 operations before ploughing.



Any deviating use is considered not matching the intended purpose. The user bears the risk of any damage and/or accidents. The above does not apply if in advance written approval has been obtained from the manufacturer!

## 2. LIABILITY AND WARRANTY

All people who use this machine and/or work on it (adjustment, maintenance) should read this manual and observe the instructions to prevent danger.

That also means:

1. That work may only be carried out within the functional limits (e.g. max. speed), as laid down in the instructions for operation, maintenance and repair.
2. That locally applying regulations for accident prevention, safety, traffic and transport are to be observed.
3. That exclusively original or equivalent parts and lubricants must be used and mounted according to the instructions. A part and/or lubricant is considered equivalent when it has been approved by the manufacturer or when it can be demonstrated that it has the properties required for the function(s) in question.
4. That changes / modifications on the machine that have not been approved in writing by the manufacturer, exclude all liability of the manufacturer for any damage.



Non-observance of the above rules shall be considered negligence. It will rule out any liability of the manufacturer for all possible damage and/or consequences. The user is fully and solely responsible for any risk!


### 3. DANGER AND SAFETY DECALS



Working safely also means that you take proper notice of the various decals on the machine. You must know what they warn you for!

There are a number of safety decals on the machine. The ones used and their place on this machine are shown on the next page.

They have the following meaning:



**Danger:**

Stop the engine and remove the key from the ignition when working on the machine!

**Attention:**

Carefully read the operating manual before taking the machine into operation!



**Danger:**

There is a risk of flying objects and / or clods!

Keep clear!



**Danger:**

Keep away from the fold-down parts when the locking pins with inserted retaining clip are not mounted!

Keep clear!



**Danger:**

There is a risk of parts folding down!

Fix the locking pins with inserted retaining clip!



**Danger:**



Never stand between the tractor and the machine when the power lift is being operated!



**Danger:**

Risk of injection at a leaking hydraulic system!

Liquid under pressure easily penetrates through skin and clothing this can cause heavy injuries!




**Danger:**

In operating position the top link must be higher on the machine side than on the tractor side!



## 4. POSITION OF DECALS



Picture 4.1 Location of decals



If decals are loose, have become illegible or are no longer on the machine, these must be replaced as well!



## 5. SAFETY INSTRUCTIONS



Read and understand these instructions before working with the machine!

If these safety instructions aren't observed, all liability of the manufacturer for any damage is excluded!

### 5.1 General

- The machine must only be used, operated and maintained by people who are familiar with the machine and who are aware of the risks!
- The operator should familiarise him-/herself with all controls and their functions before starting work. During work could be too late!
- In addition to the specific instructions of this manual, you should also study the general regulations for safety and accidents prevention in your country!

### 5.2 Road transport and use

- Always observe the road traffic regulations when using public roads!
- Check the safety of the machine and tractor before use as regards work and traffic!
- Observe the maximum permissible axle load, total weight and transport dimensions!
- Prior to road transport, check and mount transport accessories such as lighting, warning signs and any protective parts!
- Put the machine in the position intended for road transport and lock it according to the instructions!
- Always make sure that the machine has sufficient lateral stability in transport position!
- In case of road transport with the machine in lifted position, the control lever of the power lift must be locked to prevent lowering!
- Look around the machine and the tractor before driving off or starting to work. Make sure you have sufficient view. Look out for children!
- It is strictly prohibited to be on the machine during work or transport!
- The driver's seat must at all time be occupied during driving!
- Handling, manoeuvrability and brake performance are influenced by mounted machines and front weights. Therefore, make sure you work with an adequate steering and braking installation.
- Always adapt the forward speed to the condition of the terrain!
- When taking turns, take into account the length/width (turning circle) and/or swinging out, due to the large mass of the machine!
- Only work with machines with the protective provisions complete, intact and in the functional position!
- There must be nobody within the operating and danger range (including turning and swinging circle) of the machine. At the rear of the machine clods or other objects may be flung away!

- There must be nobody between the tractor and the machine, until the vehicle is prevented from moving by means of the parking brake and/or wheels chocks!
- When leaving the tractor, put the machine on the ground, switch off the tractor engine and remove the ignition key!
- The warning decals on the machine give important instructions for safe use; observing them is for your own safety!
- The user must wear closely fitting clothes. Avoid loose clothing!
- Always mount weights on the tractor according to the instructions on the fixation points intended for that purpose!

## 5.3 Mounting and dismounting

- Mount machines and accessories according to the instructions and mount the machine and/or parts/accessories only to the provisions intended for that purpose. Make sure they are locked effectively!
- Special care must be taken when mounting or dismounting the machine on or off the tractor
- When mounting or dismounting the machine on or off the three-point linkage, put the power lift control in a position in which inadvertently lifting or lowering is not possible!
- For a three-point linkage the linkage category of the machine must always match that of the tractor!
- The three-point linkage system constitutes a risk of accidents by getting caught and jack-knifing. The same risk exists with the cylinders (if mounted) and the linkage arms and lifts rods!
- The control for the three-point power lift outside the tractor cab must be operated without getting between the tractor and the machine!
- The release ropes for quick coupler should hang freely and in the lowered position must not release the quick coupler by themselves!

## 5.4 Hydraulic system

- The hydraulic system carries a high pressure!
- When connecting hydraulic cylinders the instructions for connecting hydraulic hoses must be observed!
- Hoses from the cylinders must be routed in such manner that under all transport and operating conditions they cannot cause undesirable situations and/or cannot hinder any functions!
- Never try to locate or shut off a leak in the hydraulic system with your hands. Fluid under high pressure can easily penetrate skin and clothing and it can cause severe injuries. When injured see a doctor immediately! Danger of infection!
- Ensure that the hydraulic system of the tractor and that of the machine are pressure less when connecting or disconnecting the hose!
- The hydraulically operated parts may only be operated when there is nobody within the danger zone (turning circle) of these parts!
- When hydraulically folding frame sections are in the transport position (folded up) the lock pins with inserted retaining clip must be placed in the holes intended for that purpose!
- For hydraulic connectors between tractor and machine the couplings and plugs must be

marked. When connections are interchanged, the function reverses (e.g. lifting/lowering) - Risk of accidents!

- Check the hydraulic hoses, pipes and all connections regularly and replace them in case of deterioration and damage. New hoses must satisfy the technical specifications prescribed by the manufacturer!
- Before carrying out work on the hydraulic system, the machine must be lowered to the ground and the hydraulic system must be made pressure less (move the lever of the control valve a few times back and forth with the engine switched off)!
- In transport position the control valve of the hydraulic functions must be in the neutral position!
- Always lay down a disconnected hydraulic hose in such a manner that the plug stays clean!

## 5.5 Maintenance

- Repair, maintenance and cleaning activities, as well as repairing malfunctions, must be only carried out with the tractor engine switched off. Remove the ignition key!
- When the machine must be in lifted position for repair, cleaning or maintenance, support legs must be used. Only work on a firm surface!
- Regularly check whether all bolts and nuts are still tight. Tighten if necessary!
- Parts must at least satisfy the technical specifications prescribed by the manufacturer!
- Always check whether replaced and/or dismantled parts are mounted correctly before using the machine again!
- Ensure that any damage is repaired at once before using the machine again!
- When conducting electrical welding operations on the tractor or on the mounted implement remove cable from the generator and the battery!
- Before working on the electric gear disconnect battery cables!
- For replacing any tools with cutting edges, always use the suitable tools and gloves!
- Dispose of old oils and grease as prescribed by law.
- Thoroughly clean the machine with water.
- After using the machine and/or cleaning, grease the discs and the rams of the cylinders to prevent corrosion.



After using the machine and/or after cleaning the machine with water, grease the rams of the cylinders to prevent corrosion!

## 5.6 Tyres

- Fitting tyres requires knowledge and special tools!
- When working on the tyres, make sure that the machine has been placed on the ground safely and that it is secured by shocks against unintentional rolling!
- Repair work on tyres may only be conducted by trained staff and with suitable tools!
- Check the tyres regularly and replace them in case of deterioration and damage. New tyres must satisfy the technical specifications prescribed by the manufacturer!
- Check the tension of the tyres regularly and adhere to the advised air pressure. (See table).
- In case of doubt, contact your dealer or see a tyre tension table.

Tyre	Max. speed	Min. pressure in Bar	Best pressure in Bar	Max. Pressure in Bar
195 65/15	30 km/h	2	2,5	3
10.0/75 - 15,3 14pr	40km/h	3.5	5.5	7

**Table 5.1 Tyre pressure**

## 6. MOUNTING AND DISMOUNTING



Always place the supplied pins and retaining clips and check whether they are locked securely!

The standard version is based on a three-point linkage: Category II three-point linkage. (= lift pins  $\varnothing$  28 mm, top link pin  $\varnothing$  25 mm and retaining clips  $\varnothing$  11 mm and  $\varnothing$  8 mm).

This machine can also be fitted with a Category III three-point linkage (= lift pins  $\varnothing$  36,5 mm, top link pin  $\varnothing$  31,5 mm and retaining clips  $\varnothing$  11 mm).

Do **not** use pins with a smaller diameter!


Make sure that the tree point linkage has enough stabilisation to the side! The machine should not be able to move more than 5 cm side ways.

During mounting, dismounting and transport of the machine, the power lift of the tractor must be in position control, and must be protected against accidental lowering!

### 6.1 Mounting

There are three mounting options for the top link pin. A slotted hole and 2 round holes. The slotted hole is intended for stony soils. When the machine should struck a rock, it can move upwards. The round holes are intended for soils without stones or rocks. In operating position the top link must be higher on the machine side than on the tractor side! Only in this position it is possible that the machine can move up in case of soil that is not completely flat (fig 6.1)

In stony soil the top link must be places between the special slotted holes. Ensure that the supplied slotted hole washers are placed on both sides of the top link pin. Only in the position the front gang can move up when it hits a large stone.



**Picture 6.1 The top link must be higher on the machine side than on the tractor side!**

- When setting the working depth, the top link pin must be at the back of the slotted hole.
- When the machine is in working position, the tractor's power lift must be in floating position (see the manual of the tractor).
- Adjust the check rods or chains of the tractor correctly to prevent lateral sway.



Ensure that the supplied slotted hole washers are placed on both sides of the top link pin!

## 6.2 Transport with a length transport provision

The versions with a larger working and transport with can optionally be fitted with a length transport provision. The length transport provision consists of an extra three point linkage on the side of the frame.

During transport the machine can be mounted to the tractor using this extra three point linkage. The mounting and dismounting is done in the usual way (chapter 6.1 mounting).

## 6.3 Dismounting and storing

- Make sure that the tractor hydraulic is set to position control.
- It is important to thoroughly clean the machine with water.
- The bearings and joints should also be greased as prescribed in chapter 9 Maintenance.
- Dispose of old oils and grease as prescribed by law.
- Let the machine rest on a flat soil.
- Let the roll rest on the ground or on solid wooden blocks with enough stability.
- A roll made of synthetic material **must** be supported on the metal parts by wooden blocks, the synthetic material should not touch the ground, else it will deform.
- Make sure the machine has enough stability.
- Dismount the machine from the tractor.
- Grease the rams of the cylinders to prevent corrosion.

## 7. ADJUSTING THE VARIO DISC.

### NOTE

The mounting height depends on the tyre size of the tractor. It is recommended to have the lower links as level as possible, while the top link is mounted higher to the machine than to the tractor.

It is recommended to use the crumbler roller to keep the machine steady and to make the soil more flat. On heavier soils it is possible to use the draft control of the tractor instead of a crumbler roller.

### 7.1 Adjusting the working depth

Adjusting the working depth with the crumbler roller is done as follows:

- Stop the tractor and make sure that the parking brake is set.
- Make sure that the machine is out of the ground.
- Make sure the power lift is in position control.
- Pull the machine into the ground by moving the tractor forward with the power lift of the tractor in the floating position.
- Make sure that the machine is completely horizontal, if this is not the case it can be adjusted with the top link.
- Place the pins above the roller arms of the frame, to adjust the maximum depth.
- If required, other pins can be placed under the roller arms to prevent rattling during lifting the machine out of the ground.
- If the working depth should be adjusted higher during work, the pins under the roller arms should be removed. Then the machine can be brought to the required depth by driving forward.
- Place the pins above the roller arms in the right hole.
- If the working depth should be adjusted lower during work, the pins above the roller arms should be removed after the machine is lifted. In this case there is no tension on the pins.
- Then the machine can be brought to the required depth by driving forward.
- Place the pins above the roller arms in the right hole.
- If required, other pins can be placed under the roller arms to prevent rattling during lifting the machine out of the ground.
- If the penetration of the discs is not sufficient, other pins can also be inserted under the roller arms to take advantage of the roller weight.



## 7.2 Adjusting the working depth without the roller

### This is not recommended!

It is recommended not to use the Vario-Disc without the crumbler roller on bumpy and hilly fields. In that case damage to the disc bearings can easily occur.

When working without the crumbler roller. The control hydraulics of the tractor must be adjusted(consult your tractor manual for this.

## 7.3 Adjusting the discs

The tilling intensity of the Vario-Disc can be adjusted by increasing the disc inclination. For that purpose the left hand side of the frame is fitted with a screw spindle and a graduated scale for each gang. The screw spindle is operated with a crank that has its storage place at the front-left of the frame.

The graduated scale sticker is placed in such a manner that when the disc are vertical, it indicates "0". The discs can be inclined by turning the spindle clockwise.

The required inclination degree depends on the soils type, the discs penetrate soft soil easier than hard soil. The type of stubble to till also has an influence.

Roughly it can be indicated on what position of the scale the pointer must be.

Based on a working depth of 7 cm the standard setting is:

	Front disc row	Rear disc row
Sand	10	12
Loam	12	14
Clay	17	19

**Table 7.1 Standard disc settings**

When greater working depth is set, the discs must be inclined less.

Pasture on lighter soils requires two passes. The first pass at a depth of about 4 to 5 cm with the discs in position 9/11 and a forward speed of about 7 km/h, while the sod must not be turned. And a second pass, if possible at right angles with the first one, at a depth of 6 to 7 cm and the discs in position 15/16 while the forward speed may be 10-12 km/h.

## NOTE

The indicated positions are estimates of setting that have been found in practice. Every user will find out in practice what the settings are that suit his specific soil conditions and requirements.

It is important to keep the tractor in a straight track despite the transverse force that the inclined position of the discs will always cause. The first gang runs in solid soil, the second in partly loosened soil. So in order to stabilise the transverse forces, the second gang is inclined a little more than the first one.

## 8. INSTRUCTIONS FOR USE

- Make sure that the discs are not inclined to much. That will not improve the effect and it means a waste of energy.
- The maximum permissible working depth is 10 cm. At a greater depth setting the discs and bearing houses will wear too quickly.
- The machine performs optimally at a forward speed between 8 and 12 km/h. higher speeds will cause an increase of wear and so of costs.
- The maximum tractor power per meter working width is 27 kW or 37 HP.
- We recommend not to use the Vario-Disc on soil that contains many heavy rocks (rocks > 15 cm).
- It is forbidden to make tight straight angles with the machine in working position.
- The machine can only work properly when travelling forward.
- Set the rate of drop of the power lift in such a manner that when lowering into the soil or putting down, the machine does not bump on the ground, so as to prevent damage to tines and shares.

## 9. MAINTENANCE



See chapter 5 “SAFETY INSTRUCTIONS” sub 5.5 “Maintenance”



When the machine is in lifted position for repair, cleaning and maintenance activities, support legs must be placed under the machine and it must rest on them.  
Switch off the engine and remove the ignition key!

### 9.1 General

- Regularly check whether all bolts and nuts are tight.
- Also check the bearings of the roller regularly.
- After maintenance it should always be checked whether the bearings are remounted correctly.
- Check the hydraulic hoses, pipes and all connections regularly and replace them in case deterioration or damage.
- After every use the machine should be cleaned with water.
- When the machine has been in contact with manure, the bearings of the roller must be filled with grease, that to counteract the aggressive influence of ammonia.
- It is important to thoroughly clean the machine with water. It is recommended to grease the discs and the rams of the cylinders to prevent corrosion!



After using the machine and/or after cleaning the machine with water, grease the rams of the cylinders to prevent corrosion!



The disc blades are sharp. Avoid wrenches slipping when working near the disc blades. Avoid climbing on machine above the disc gangs where there is possibility of slipping or falling. Serious injury could occur!

## 9.2 Lubrication

Grease nipples are installed in the following places.

- a) The bearings of the disc.
- b) The spindles and their bushes.
- c) The holders (bushes) of the disc shafts.
- d) The bearings of the roller.

- a) Every 25 working hours

The disc bearings must be topped up with grease every 25 working hours, after cleaning the grease nipples, with a properly working manual grease gun, until pressure is clearly felt. Usually two strokes of the gun will suffice. Directly after greasing, the disc must be turned at least one revolution. Never use a compressor gun. Too high pressure can damage the grease sealing ring, causing fine soil particles to enter the bearing house. When the machine will not be used for an extended period, it is recommended to apply a coat of grease or oil over them, particularly when the machine has been in contact with manure. Dispose of old oils and grease as prescribed by law.

- b) Twice a year

The spindles must only be operated when the machine has been lifted and the discs are clear of the ground. To lubricate the thread sufficiently it is important to screw in the spindle as far as possible (to about 25 on the scale) then apply grease and subsequently screw back the spindle to operation position. That way two strokes of the grease gun twice a year will suffice.

- c) Twice a year

- d) Every 25 working hours

## 9.3 Standard disc bearing

This bearing house has two tapered roller bearings that must be adjusted. The play must be minimal. After some 25 working hours of operation the play must be checked and, if necessary, compensated.

This is done as follows:

- Screw off the cover cap.
- Remove the locking pin from the castle nut.
- Tighten the castle nut until the bearing begins to drag.
- Reverse the castle nut one locking pin hole.
- Put back the locking pin.
- Place the cover cap back on the assembly.

### NOTE

The first 25 working hours (with new bearings) you have to check the play regularly and adjust it directly if necessary.  
Regular inspection and adjustment of the bearings is essential to

## 10. TECHNICAL SPECIFICATIONS

Technical specifications Vario-Disc Skyros:

Type	V125/51	V150/51	V175/51	V200/51	V225/51	V250/51
Working width (cm)	125	150	175	200	225	250
Transport width (cm)	175	200	225	250	275	300
Transport length (cm)	240	240	240	240	240	240
Working depth max (cm)	10	10	10	10	10	10
Diameter disc (cm)	51	51	51	51	51	51
Number of discs	10	12	14	16	18	20
Rows of discs	2	2	2	2	2	2
Tractor power (HP)	20-45	25-55	30-65	40-70	45-75	55-90
Tractor power (kW)	15-33	18-40	22-48	30-51	33-55	40-66
Linkage category	II	II	II	II	II	II

Type	V275/51	V300/51	V325/51	V350/51	V375/51	V400/51
Working width (cm)	275	300	325	350	375	400
Transport width (cm)	325	350	375	400	425	450
Transport length (cm)	240	240	240	240	240	240
Working depth max (cm)	10	10	10	10	10	10
Diameter disc (cm)	51	51	51	51	51	51
Number of discs	22	24	26	28	30	32
Rows of discs	2	2	2	2	2	2
Tractor power (HP)	60-100	70-115	75-120	85-135	90-140	100-150
Tractor power (kW)	44-74	51-85	55-88	63-100	66-103	74-110
Linkage category	II	II	II	II	II	II

Mass (kg) of the Vario-Disc Skyros:

Type	Mass (kg), including crumbler roller, with 1 ¼" tube.	
	Roll 45 cm	Roll 62 cm
V125/51	665	720
V150/51	733	788
V175/51	801	856
V200/51	869	924
V225/51	937	992
V250/51	1007	1068
V275/51	1075	1138
V300/51	1144	1208
V325/51	1212	1278
V350/51	1279	1355
V375/51	1347	1423
V400/51	1415	1491

The noise level of the Vario-Disc Skyros does not exceed 70dB(A) during work.

## 11. ORDERING PARTS

Contact your local dealer to order spare parts.

Please state the following data when ordering parts.

1. Machine Type (MT) and the production identification number (PIN), these data can be found on the EC certificate of conformity.
2. Name, article number and quantity of the article.

If you are not sure of the correct part number of a part, you can take it to your local dealer or send in the original to prevent incorrect delivery.



If decals are loose, have become illegible or are no longer on the machine, these must be replaced as well!

## 12. EC CERTIFICATE OF CONFORMITY

**EG-VERKLARING VAN OVEREENSTEMMING**  
**EC-DECLARATION OF CONFORMITY FOR MACHINERY**  
**EG-MASCHINENÜBEREINSTIMMUNGSERKLÄRUNG**  
**DÉCLARATION DE CONFORMITÉ "CE" POUR MACHINES**

*Fabrikant/Manufacturer/Fabrikant/Fabricant:*

**EVERS AGRO B.V.**

*Adres/Address/Adresse/Adresse:*

**Bedrijvenpark Twente 326**  
**7602 KL Almelo**  
**The Netherlands**

*Verklaart hier mee dat/Herewith declares that/Erklärt hiermit das/Déclaré ci-après que*

Machine type/Machine type/Maschine Type/Type de machine:

Ordernummer/Order number/Bestellnummer/Numéro de commande:

Naam/Name/Name/Nom:

Machine/Machine/Maschine/Machine:

Product identificatie nummer/Product identification number/

Produkt Identifikation Nummer/ Numéro l'identification de produit:

Gewicht/Weight/Gewicht/Masse:

*Paste sticker here*

- *Voldoet aan de bepalingen van de Machinerichtlijn (Richtlijn 2006/42/EG, zoals laatstelijk gewijzigd) en de nationale wetgeving ter uitvoering van deze richtlijn;*
- *Is in conformity with the provisions of the Machine Directive (Directive 2006/43/EC, as amended) and with national implementing legislation;*
- *Konform ist mit den einschlägigen Bestimmungen der EG-Maschinenrichtlinie (EG-Richtlinie 2006/42/EG), inklusive deren Änderungen, sowie mit dem entsprechenden Rechtserlaß zur Umsetzung der Richtlinie in nationales Recht;*
- *Est conforme aux dispositions de la Directive "Machines" (Directive 2006/42/EC telle que dernièrement modifiée) et la législation nationale adoptée en application de ladite directive.*

**Almelo, 16 May 2012**

**G.J. Kamp,**  
**Director**




## APPENDIX I: MOUNTING INSTRUCTIONS AND PARTSLIST

### I.1 Recommended machine placement for mounting the hubs and discs:




If the frame is NOT propped as recommended during installation of the hubs and discs, it is liable to tip over! Therefore it is also recommended that the front row of the discs are mounted first. Furthermore, the back of the frame should be suspended from, for instance, a hoist as an extra safety measure against tipping over.

## I.2 Vario disc Ø 51/56 Cm






Part no.	Description
990520	Bearing complete 5 holes with 2 greasing nipple
994076	Hexagon head bolt M14x75 ( threadlength 25 mm) mounting bearing to leg.
100114	Prevailing torque type hexagon nut with plastic insert M14
995022	Disc-leg 42CrMo4 Ø14,5 mm
992021	Adjusting ring Ø 70 mm for disc leg Vario-disc
992022	Allen head bolt(inside) M10x20 for adjusting ring Ø 70 mm
992023	Synthetic dust cap for adjusting ring (Ø 70 mm)
131605	Hexagon head bolt M16x50 ( threadlength 25 mm) (Mounting leg to strip)
131606	Hexagon head bolt M16x60 ( threadlength 25 mm) (mounting leg to disc adjustment)
100116	Prevailing torque type hexagon nut with plastic insert M16
990183	Disc, knurled Ø510 mm, Thickness 6 mm
141202	Bolt M12x20
100312	Spring lock washer M12
992050	Adjusting spindle shaft Ø25 mm, complete
992051	Crank shaft Ø25 mm
992052	Clamp lever M10x25
992045	Scale 0-25

## I.3 Assembly hub Vario-disc




	Part no.	Description
A	995012	Hub Vario-disc 5 holes, castle nut M30x1,5
B	993011	Circlip Ø 62x2 mm
C	993003	Sealing ring "Stefa" 40x62x10
D	996010	Cover-ring hole Ø 40mm, 2,5mm thick
E	992004	Taper roller bearing 32007
F	992037	Grease nipple M10x1,00 180°
G	996001	Bearing housing 5 holes with 1 greasing nipple
G*	995013	Bearing housing 5 holes with 2 greasing nipple
H	994005	Taper roller bearing 32206
I	994007	Castle nut M30x1,5
J	994008	Tension pin Ø 6mm
K	994012	Dust cap M68x2
L	992059	Spanner for dustcap
N	990520	Hub Vario-disc 5 holes with 2 greasing nipple complete
O	994076	Hexagon head bolt M14x75 ( threadlength 25mm )
P	100114	Prevailing torque type hexagon nut with plastic insert M14
Q	141202	Hexagon head bolt M12x20
R	100312	Spring lock washer M12

## I.4 Tube roller




Pos.	Part no.	Description
A	121205	Allen head bolts M12X50
B	990212	Circlip for shaft Ø 35 mm
C	990200	Bearing SBF207, shaft Ø 35mm
D	100112	Prevailing torque type hexagon nut with plastic insert M12
E	121606	Allen head bolts M16x60
F	990229	Circlip for shaft Ø 50 mm
G	990227	Bearing UCF210, shaft Ø 50mm
H	100116	Prevailing torque type hexagon nut with plastic insert M16
I		Supporting arm
J	100120	Prevailing torque type hexagon nut with plastic insert M20
K	100220	Plain washer M20
L	990435	U- bolt M20 inside 100mm


## I.5 Lower hitch pin / top link pin / depth control pin



A





B



C

Pos.	Bestelnr.	Omschrijving
A	992204	Lower hitch pin Ø 28,0 mm Cat. 2
A	992208	Lower hitch pin Ø 36,5 mm Cat. 3
B	992205	Lower hitch pin Ø 25,0 mm
B	992207	Lower hitch pin Ø 31,5 mm
C	992206	Depth control pin / Support leg Ø 20 mm

## I.6 Identification plate, patent plate and safety decals



Pos.	Part no.	Description
A	992061	Identification plate
B	992062	Patent plate, Evers disc harrow Vario-Disc
C	992054	Safety decal "Read operation and safety instructions"
D	992055	Safety decal "Do not stay between tractor and machine"
E	992056	Safety decal "Keep clear"
F	992057	Safety decal "Keep away from folding parts"
G	992058	Safety decal "Fix locking pins with inserted retaining clip"
H	992066	Attention decal "Correct mounting topline between tractor and machine"
I	992063	Safety decal "Watch out for hydraulic leakings"